

TTmatic 505 - Characteristics

Two rotating heads make it possible to play complete different strokes.
For example head A backspin and head B topspin.
These basic strokes can be adjusted individually by the electronic control desk.
The PST (Power Spin Technology) assures an independent adjustment of speed and spin. As a consequence the balls shot by the TTmatic robots have a specific natural trajectory.

It is possible to play short sequences from 1 until 36 balls, but also a continuous operation until to manual stop.

Control Desk

5 Channels – every channel has 5 knobs for to adjust the different functions:

1. Shot from head A or B
2. Speed
3. Position left-right
4. Number of balls until change to the next channel.
5. Ball frequency

With a rotary switch one single channel or a channel chain can be selected.
So single strokes can be trained as well as complete ball sequences.
The additional random mode allows playing balls from all five channels.